



Disassembling Speak And Spell Case

Here's how to open up the Speak And Spell case.

Written By: bushing





TOOLS:


- [Phillips #1 Screwdriver](#) (1)
 - [Spudger](#) (1)
-

Step 1 — Case



- Flip the toy over, so that the keypad is facing away from you.
 - Remove two Phillips-head screws.
 - Insert a plastic spudger (or 4!) into the marked holes, and push down and towards the edge to release each catch.
- i** It's possible to release each catch one-at-a-time, but easier if you have 4 tools and do them simultaneously.
- !** This requires quite a bit of force; be careful.

Step 2



- Separate the two halves of the case to expose the inner PCB, speaker and battery holder.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-22 06:15:02 PM.